

# Minerva Pattern 2053

# Double-Breasted Coat Dress with Flared Skirt & 3/4 Sleeves

Introducing a digital dress sewing pattern for an elegant dress-coat – Timeless Sophistication with a Double-Breasted Twist.

# When To Wear Design 2053

This dress-coat is versatile yet refined, making it suitable for a range of occasions:

- Chic Everyday Wear: Pair it with heels or ankle boots for a polished daytime look.
- Evening & Special Events: Its structured lines and double-breasted front give it a formal edge, making it perfect for cocktail parties, elegant dinners, or cultural events.
- Professional Settings: A modern alternative to a classic blazer—ideal for business-casual settings or creative industries.
- Seasonal Wear: Best suited for spring and autumn. Its structured design offers warmth without bulk, while the flared silhouette makes it easy to layer.

# **Key Design Features**

Silhouette: Fitted at the waist with structured paneling that creates a flattering flared skirt.

Double-Breasted Front: Clean, symmetrical design with six buttons for closure.

Sleeves: 3/4 set-in sleeves with a tailored finish.

Construction Lines: Princess seams at the front and back for a tailored fit.

Style: A blend of classic tailoring and modern elegance—structured, refined, and subtly feminine.

# **Level Of Difficulty**

# Intermediate.

# **Fabric Recommendations**

Lightweight coat fabrics made from natural or blended fibers work best for this design. The dress-coat can be lined or unlined depending on the desired level of structure and warmth.

# **Additional Supplies**

- Lining: viscose, silk, polyester.
- Fusible Interfacing.
- Closure: 6 buttons for front, 3 flat buttons for inside.



• Additional notions: small shoulder pads and sleeve heads.

# **Cutter's Must**

#### From Main Fabric:

- 1. Upper Center Back 2 pieces
- 2. Upper Side Back 2 pieces
- 3. Lower Center Back 2 pieces
- 4. Lower Side Back 2 pieces
- 5. Center Front 2 pieces
- 6. Side Front 2 pieces
- 7. Lower Center Front 2 pieces
- 8. Lower Side Front 2 pieces
- 9. Sleeve 2 pieces
- 10. Back Neckline Facing 1 piece
- 11. Center Front Facing 2 pieces

# From Lining Fabric:

From the lining, cut the below pieces using the main patterns with the following modifications:

- 1. Upper Center Back exclude Back Neckline Facing area, cut 2.
- 2. Upper Side Back exclude Back Neckline Facing area, cut 2.
- 3. Lower Center Back cut 2.
- 4. Lower Side Back cut 2.
- 5. Upper Front Lining 2 pieces.
- 6. Lower Center Front exclude Center Front Facing area, cut 2.
- 7. Lower Side Front cut 2.
- 8. Sleeve cut 2.

# From Fusible Interfacing:

- 1. Back Neckline Facing 1 piece
- 2. Front Facing 2 pieces
- 3. Upper Center Front 2 pieces
- 4. Lower Center Front 2 pieces



# **Important Information**

Before cutting your fabric:

- Print and lay out pattern pieces to determine yardage.
- Check mirrored pieces, notches, and grainlines.
- For patterned fabrics, align carefully for symmetry.

#### **ASSEMBLY INSTRUCTIONS**

#### Preparation

# **Fuse Interfacing**

From the wrong side, apply fusible interfacing to Back Neckline Facing, Front Facings, Upper and Lower Center Front pieces - Press thoroughly with a hot iron and press cloth until fully bonded.

# **Back Assembly**

- 1. Stitch upper side back pieces to upper center back; press seam allowances open.
- 2. Stitch lower side back pieces to lower center back; press seam allowances open.
- 3. Join upper and lower back sections together, aligning seams; press allowances open.

# **Front Assembly**

- 1. Stitch upper side front pieces to upper center front; press allowances open.
- 2. Stitch lower side front pieces to lower center front; press allowances open.
- 3. Join upper and lower front sections together; press allowances open.

# **Main Body Assembly**

- 1. Join shoulder seams; press open.
- 2. Stitch side seams; press allowances open.

# **Sleeves**

- 1. Stitch sleeve seams; press allowances open.
- 2. Ease sleeve caps between notches and set sleeves into armholes, distributing ease evenly.
- 3. Stitch and press seam allowances toward sleeves.



# **Facings**

- 1. Join shoulder seams of Front Facings and Back Neck Facing; press allowances open.
- 2. With right sides together, stitch facings to the coat along the front edges and neckline.
- 3. Clip curves, trim corners, turn right side out, and press for a clean edge.

# **Lining Assembly**

- 1. Assemble lining in the same order as the main garment, leaving a 20 cm opening in the left sleeve seam for turning.
- 2. Attach lining to the facings along the front edges and neckline.
- 3. Press neckline seam toward lining.

#### **Hem & Sleeves**

- 1. Stitch lining to coat hem and sleeve hems, ensuring lining is 2 cm shorter to form an ease pleat.
- 2. Turn the coat right side out through the sleeve opening.
- 3. Close the opening neatly by hand or machine stitch.

# **Finishing**

- 1. Work buttonholes on both fronts as marked.
- 2. Sew main and inside buttons.
- 3. Give the garment a final press, shaping the neckline and sleeve heads on a tailor's ham.

Discover more styles tailored to your custom measurements at MinervaPatterns.com